



County of Fairfax, Virginia

To protect and enrich the quality of life for the people, neighborhoods and diverse communities of Fairfax County

Rules & Regulations for the I-66 Transfer Station Complex

I-66 TRANSFER STATION COMPLEX RULES AND REGULATIONS

4618 West Ox Road, Fairfax, Virginia 22030

(Effective May 2019)

703-631-1179

In order to provide efficient and economical disposal service, the following rules will be strictly enforced at Fairfax County's I-66 Transfer Station Complex.

AREAS OF THE I-66 TRANSFER STATION

Collection and disposal companies will deliver their municipal solid waste (MSW) into the I-66 Transfer Station Complex building for processing. Companies may bring materials such as yard waste, brush and metals to the Recycling and Disposal Center (RDC).

Residents of Fairfax County and Commercial Cash (CC) customers will dispose of waste and deliver recyclable material to the RDC.

Residents who wish to dispose of household hazardous waste (HHW) will use the Household Hazardous Waste Disposal Facility located at the I-66 Transfer Station.

Residents who wish to dispose of electronics (e-waste) will use the Electronics Recycling Disposal Facility located at the I-66 Transfer Station.

It is the responsibility of the customer to immediately remove any unauthorized solid waste discharged at the I-66 Transfer Station RDC.

ALLIANCE DRIVE

Drivers are not permitted to use Alliance Drive. Tickets may be issued to truck drivers using this roadway, and Transfer Station personnel may suspend drivers from disposing their loads.

I-66 RECYCLING and DISPOSAL CENTER

Clean brush, yard waste and metals/white goods will be delivered to the I-66 Transfer Station's Recycling and Disposal Center (RDC) areas designated for such materials. Yard waste consists of leaves, grass and twigs. Clean brush is the wood portion of yard waste, such as tree trimmings (including Christmas trees). The I-66 RDC can accept a branch and/or trunk with a diameter of 20 inches or less. Metals/white goods include, but are not limited to, appliances such as stoves,

**Department of Public Works and Environmental Services
Solid Waste Management Program**

12000 Government Center Parkway, Suite 458
Fairfax, Virginia 22035

Phone: 703-324-5230, TTY: 711, Fax: 703-324-3950

www.fairfaxcounty.gov/dpwes



I-66 TRANSFER STATION COMPLEX RULES AND REGULATIONS

washing machines, clothes dryers, metal dishwashers (not plastic dishwashers), and hot water heaters. Other metal objects include aluminum siding, metal shelving, metal lawn furniture, lawn mowers (gas or batteries must be removed), and smaller objects that are primarily made of metal. Refrigerant containing metal appliances/white goods, which require evacuation recovery prior to recycling are also accepted for a fee. These items are collected in a separate area adjacent to the metals/white goods area and include, but are not limited to, refrigerators, freezers, air conditioning units (A/Cs), watercoolers, humidifiers, and dehumidifiers.

CONSTRUCTION & DEMOLITION DEBRIS

Commercial loads of dirt, concrete (cement blocks), asphalt, rock (granite, slate, etc.), and brick will not be accepted at the I-66 Transfer Station Complex.

CUSTOMERS AT THE I-66 TRANSFER STATION COMPLEX

Customers must obey the following rules in order to ensure the safe and efficient operation of the I-66 Transfer Station Complex. Failure to comply may result in the suspension of the individual(s) and the company from using the complex. The I-66 Transfer Station Complex Manager or his/her designee will determine the duration of any such suspension. At the discretion of the I-66 Transfer Station Complex Manager or authorized designee, the restriction may begin immediately or be scheduled based upon the circumstances. The I-66 Transfer Station Complex Manager or his/her designee will telephone or email the company owner/representative to relay the specific circumstances and duration of any suspension.

GENERAL REGULATIONS

- 1) All individuals entering the I-66 Transfer Station Complex must conduct themselves in an orderly manner and follow the oral/written instructions of County personnel.
- 2) County solid waste permit decals must be clearly displayed on both sides of collection and disposal vehicles.
- 3) The speed limit at the I-66 Transfer Station Complex is 15 mph. *Drive safely* and minimize your speed when entering or leaving the facility. Follow road signs and adjust driving speeds to road conditions during inclement weather. All road maintenance vehicles and snow removal equipment have the RIGHT-OF-WAY, including waste loaders and other County equipment operating in and around the tipping floors, as well as throughout the complex.
- 4) All commercial vehicles entering the I-66 Transfer Station Complex are subject to random vehicle waste inspections by County personnel. In the event of a solid waste inspection, drivers are to remain with their vehicle until informed by County personnel that they may proceed to exit the I-66 Transfer Station.
- 5) No person will use or possess intoxicating beverages or illegal drugs while on the property of the I-66 Transfer Station Complex.
- 6) All persons/vehicles enter the I-66 Transfer Station Complex at their own risk.

I-66 TRANSFER STATION COMPLEX RULES AND REGULATIONS

- 7) The County of Fairfax assumes no liability for damages to vehicles or injuries to individuals on the I-66 Transfer Station Complex premises. Report any accident immediately to the I-66 Transfer Station Manager or his representative.
- 8) Use of the I-66 Transfer Station Complex is limited to commercial companies with valid collection or disposal permits, residents and government agencies.
- 9) Fairfax County reserves the right to change or modify these rules without written notice.
- 10) Out-of-State waste cannot be accepted for disposal at the I-66 Transfer Station Complex, unless specifically approved in writing by the agency director.

I-66 TRANSFER STATION COMPLEX RULES AND REGULATIONS

VEHICLE REGULATIONS

- 11) Drivers must remain with their vehicles. Minor repairs to vehicles may be made with the approval of the I-66 Transfer Station Complex Manager or his designee. Vehicles may not be repaired or abandoned at the facility. Any abandoned vehicle will be towed at the owner's expense.
- 12) The County of Fairfax assumes no liability for the towing of any vehicle.
- 13) Tailgates are not to be unlatched at the scale area. Tailgates are to be opened and closed while on the tipping floor only, unless otherwise instructed.
- 14) No open-top roll-off containers are allowed unless carrying grass, brush, leaves, metal, or under special circumstances previously arranged.
- 15) All open top or roll-off containers, including compactors, must have the county's "Box Number" prominently displayed. Box Numbers are obtained at the I-66 Permit Office.
- 16) All waste disposal vehicles with materials that could blow out of the vehicle must be covered during transport. This includes empty open-body type vehicles that have finished disposal and may contain loose refuse. The cover may only be removed at the disposal area.
- 17) All solid waste collection vehicles using the I-66 Transfer Station Complex must have operating back-up alarms.

DRIVER REGULATIONS

- 18) Drivers must be aware of County residents and smaller vehicles entering and leaving the I-66 Transfer Station Complex and RDC.
- 19) Drivers must enter and exit the scales slowly and stop smoothly to prevent damage to the scale equipment.
- 20) Drivers must immediately remove any unacceptable waste discharged at the I-66 Transfer Station Complex.
- 21) Drivers must state the ORIGIN and TYPE OF MATERIAL of the waste to be disposed. ORIGIN means where the waste was collected.
- 22) Drivers, whose routes or collection locations include a medical facility, clinic, medical complex or doctors' offices where medical procedures are performed, must alert scalehouse staff when entering the I-66 Transfer Station Complex.
- 23) Drivers of trucks with hydraulic leaks will be responsible for their own spills. Trucks with repeated problems may be banned from the site until adequate maintenance is performed.
- 24) Drivers may not use, AM-FM, CB, and/or two-way radios while on the scales or the tipping floor, and should limit their use at all other times while at the I-66 Transfer Station Complex. Cell phone use is not permitted.
- 25) Drivers may not use horns on site unless for safety or emergency purposes.
- 26) Drivers are responsible for the removal of any litter blown from their vehicles onto the roads of the facility.

I-66 TRANSFER STATION COMPLEX RULES AND REGULATIONS

- 27) **Drivers and all other personnel must wear safety vests with reflective material or clothing with reflective markings (orange or yellow) while out of their vehicles at the I-66 Transfer Station Complex.**
- 28) Drivers must **NOT** allow passengers to be out of the vehicle at the scale area. Drivers of other vehicles may not see a passenger. Passengers should remain in the vehicle or be let out in the parking lot.
- 29) **Drivers must notify scale personnel immediately in the event of a vehicle fire/hot load and follow the instructions given by County Personnel.**
- 30) If potential violations are noted during random or scheduled inspections, drivers must sign the inspection form used to document the issue for recordkeeping purposes. Signature does not indicate agreement with the alleged rules violations.
- 31) Drivers will not dispose of recyclable materials, brush, yard waste, or other special or prohibited waste on the tipping floor.
- 32) Drivers, helpers and their vehicles **MUST MAINTAIN A MINIMUM DISTANCE OF 15 FEET FROM ALL OPEN PITS AT ALL TIMES.**

SUSPENSION OF DISPOSAL PRIVILEGES

The Solid Waste Management Program (SWMP) reserves the right to immediately suspend disposal privileges or charge a higher penalty rate for loads in the event of:

- Nonpayment of solid waste disposal fees or delinquent accounts.
- Disposal of unacceptable or hazardous waste.
- Failure to have a vehicle properly permitted and inspected.
- Operating vehicle and/or container with safety deficiencies or in an unsafe manner.
- Salvaging and/or removal of unauthorized items from discharged waste.
- Noncompliance with rules and regulations concerning the I-66 Transfer Station Complex or Chapter 109.1 of the County Code.
- Disposal of items, which, at the discretion of the Complex Manager or his representative, may impede operations or are considered hazardous to personnel.
- Unacceptable behavior, as determined by County operations staff.
- Mixing recyclable materials with municipal solid waste.
- Driver giving incorrect information about the origin or type of waste being disposed.

I-66 TRANSFER STATION COMPLEX RULES AND REGULATIONS

FACILITY INFRACTIONS

Offense	1st Action	2nd Action	3rd Action	Comments
Mis-Identification of Waste, Origin & Material Type	1 Load @ \$100/Ton	3 Loads @ \$100/Ton	6 Loads @\$100/Ton	4 th Action – Mandatory Meeting with LIS Branch Chief at County’s Discretion
Unsatisfactory Waste Inspections	1 Load @ \$100/Ton	3 Loads @ \$100/Ton	6 Loads @\$100/Ton	4 th Action – Mandatory Meeting with LIS Branch Chief at County’s Discretion
Non-Compliance with Other Facility Rules & Regulations	1 Load @ \$100/Ton	3 Loads @ \$100/Ton	6 Loads @\$100/Ton	Facility Manager Discretion
Failure to Attend Mandatory Meetings	1 Load @ \$100/Ton	3 Loads @ \$100/Ton	6 Loads @\$100/Ton	Directory Review and Signature at 2 nd and 3 rd Action
Failure to Comply with WD/DA	1 Load @ \$100/Ton	3 Loads @ \$100/Ton	6 Loads @\$100/Ton	4 th Action – Mandatory Meeting with LIS Branch Chief at County’s Discretion

I-66 TRANSFER STATION COMPLEX RULES AND REGULATIONS

MATERIALS PROHIBITION LIST

The following materials are not accepted on the tip floor at the I-66 Transfer Station Complex, although some of the specified prohibited materials are accepted for recycling elsewhere on the Complex. Residents, see RDC brochure for additional services. Fairfax County businesses can visit our Very Small Quantity Generator page for information about Hazardous waste disposal options at:

<https://www.fairfaxcounty.gov/publicworks/recycling-trash/very-small-quantity-generators>

Recyclable Materials Accepted at the I-66 Transfer Station Complex or Recycling and Disposal Center
<input type="checkbox"/> Yard Waste
<input type="checkbox"/> Brush
<input type="checkbox"/> Ferrous Metal/White Goods
<input type="checkbox"/> Up to 10 tires (Residents Only)
<input type="checkbox"/> Cardboard
Not Accepted at the I-66 Transfer Station Complex
<input type="checkbox"/> Out-of-State Waste
<input type="checkbox"/> Dirt/Soil/Sand
<input type="checkbox"/> Stone/Gravel/Rock
<input type="checkbox"/> Concrete/Cement/Brick/Block
<input type="checkbox"/> Asphalt/Tar
<input type="checkbox"/> Friable Asbestos/Asbestos Rock
<input type="checkbox"/> Asbestos/Plaster
<input type="checkbox"/> Petroleum Contaminated Soil
<input type="checkbox"/> Hazardous Waste (With the exception of qualifying and program registered Very Small Quantity Generators – VSQGS on specified business hazardous disposal days throughout the year.) Website Link: https://www.fairfaxcounty.gov/publicworks/recycling-trash/very-small-quantity-generators
<input type="checkbox"/> Explosives
<input type="checkbox"/> Medical Waste
<input type="checkbox"/> Radioactive Material
<input type="checkbox"/> Incinerator Residue/Ash
<input type="checkbox"/> Empty Metal or Plastic Drums (Note: These are not permitted unless all contents/residues have been completely removed prior to disposal and the drum has been cut in half. Previous contents must be disposed of in accordance with all federal, state, and local regulations)

I-66 TRANSFER STATION COMPLEX RULES AND REGULATIONS

Not Accepted at the I-66 Transfer Station Complex
<input type="checkbox"/> Creosote Treated Lumber
<input type="checkbox"/> Large Stumps/Sawdust (Note: Stumps with a 20” diameter or small are permissible)
<input type="checkbox"/> Tires from Businesses
<input type="checkbox"/> Tires On Rims
<input type="checkbox"/> Offal/Dead Animals
<input type="checkbox"/> Sludge/Sewage/Manure
<input type="checkbox"/> Storage Tanks
<input type="checkbox"/> Somat/Pulverized Paper

CUSTOMER SERVICE OR EMERGENCY CONTACT

In the event that a customer has a problem that is unresolved by scalehouse staff, or if an emergency arises, customers should contact the I-66 Transfer Station management for resolution of the matter at 703-631-1179.

Authorized Company Representative: _____

Date: _____