


WINvote™ VOTING MACHINE

INSTRUCTIONS FOR CASTING A WRITE IN VOTE

Step 1:

SELECT WRITE IN



To cast a write in vote, **LIGHTLY touch the Write In box**, which is located at the bottom of the Office's list of candidates on the ballot screen.

A Write In Keyboard screen will immediately be displayed.

Step 2:

TYPE NAME OF WRITE IN




Spell out the name of the person you wish to write in by LIGHTLY touching the letters on the keyboard. The name will appear in the Name field which is located near the top of the keyboard.

When you have completed entering the name, **LIGHTLY touch the Enter button**, which is located in the lower right-hand side of the screen.

A Write In verification screen will be displayed.

Step 3:

VERIFY NAME OF WRITE IN




To change or cancel your Write In vote, LIGHTLY touch "No".

OR

If you are satisfied with your Write In vote, LIGHTLY touch "Yes" to return to the Ballot screen.

Step 4:

BALLOT SCREEN



The name of your write in candidate has been added.

A red "✓" will appear and your write in candidate's name will be highlighted in red.

When you are satisfied with **ALL** your selections, **LIGHTLY touch NEXT**, which is located in the lower right-hand side of the screen to continue.

Review your write in vote on the summary screen.